

this guide covers..

FLEXI

models

Flexi 1GTS

Flexi 2GATS

Flexi 5GTS

Flexi 6GATS



DYNAMIK

models

Dynamik 1GTS

Dynamik 2GATS

Dynamik 3GTS

Dynamik 4GATS

Dynamik 5GTS

Dynamik 6GATS



HEALTH & SAFETY
ADVICE

Correct Sitting Position



the image depicts the optimum seating position

Seat Height

Hips are slightly higher than knees (this may require a footrest)

Lumbar Support

Adjust the height of the backrest until the outward curve of the backrest sits in the inward curve of your lower back (small of the back just above the belt line)

Seat Slide

Slide seat backwards or forwards until a comfortable position is reached. If the chair is in 'free float' you may find it more comfortable to slide the seat further forward. This adjustment is purely for your comfort.

Free Float

Once sitting comfortably, unlock the chair and sit in free float mode. If the resistance is too high/loose adjust with tension adjustment knob **3** (see inside for diagram).

Headrest (when fitted)

This is to be used when reclining as a rest and will not support the head whilst working at a computer desk etc.

Adjustable Arms

Either drop underneath the desk, so that your arms are resting on the desk or raise them up so that your arms are supported in a relaxed posture with no tension in the shoulders.



Synchro Mechanism

the mechanism shown applies to all products covered

1 Gas Height Adjustment

To raise the seat height, take weight off chair and pull handle ① up towards the seat. To lower the height, remain seated and pull handle up towards the seat.

2 Mechanism Release

it is recommended that the mechanism is always in free float mode. Push lever ② down to 'lock' mechanism, pull up towards the seat to 'free float'.

3 Free Float Tension Adjustment

In order to find the most comfortable level of resistance whilst in free float, turn knob ③ clockwise to tighten and anti-clockwise to loosen the tension.

4 Sliding Seat

Pull lever and move seat to the required position.



5 Back Height Adjustment

The back works on a 'ratchet' mechanism with a total of 7 positions. Pull the back up - a click will be heard through each position. Set back to correct position - contour of the back of the chair should sit in the small of the back. After reaching the 7th click the back will drop back to its lowest position.



6 Adjustable Height Arms

Pull the lever **A** on the side of the arm up and adjust the height of the arm by sliding up and down.

The width of the arm **B** can be adjusted by sliding the pad outwards on the Flexi and the entire arm on the Dynamik (using lever under the arm)

The arm pad **C** can also be adjusted backwards and forwards by sliding the pad.

The arm pad can be angled **D** inwards and outwards by twisting the pad either way.





HEALTH & SAFETY ADVICE

if you encounter any problems or need advice please
telephone or visit our website for more information

www.sellagroup.co.uk
t: 0161 761 6889



USER GUIDE